Philips VisaCare
Replacement Tip

Sensitive Skin

SC6890

Replacement Tip for Sensitive Skin

For use only with Philips VisaCare microdermabrasion: used in the comfort of your home, the combined exfoliation and vacuum massage gently stimulate your skin's natural renewal processes and reduce the first signs of aging.

Easy to replace exfoliating tip
- Designed for Sensitive skin and Dry skin

Exfoliation tip Sensitive
- Microdermabrasion tip for mild treatment
- Replace every 6 months

PHILIPS

Replacement Tip
Sensitive Skin

SC6890/01

Specifications

Benefits
- Type of skin: For sensitive skin

Ease of use
- Cleaning: Wash under fresh water
- Compatible with: Philips SC6220, Philips SC6240
- Recommended replacement: Every 6 months
- Replacement: Easy click-on tip

Highlights

Easy fit
Easy to fit and compatible with Philips SC6220 and SC6240.

Microdermabrasion tip
Recommended to use for women with sensitive skin or in periods when the skin is more sensitive due to seasonal or hormonal chnages, or skin, new to microdermabrasion treatments. Developed with dermatologists, safe for home use. When using a new tip, always start again with a limited number of passes; allowing your skin to get used to iets more intense treatment.*

Replace every 6 months
For optimal results, it is recommended te replace the microdermabrasion tip every six months.

Issue date 2014-05-10

Version: 4.2.1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com